EAST ELEVATION
SCALE: 1 : 100

07-PARAPET LEVEL FFL +142750
06-ROOF LEVEL FFL +141350
05-FOURTH FLOOR FFL +138200
04-THIRD FLOOR FFL +135050
03-SECOND FLOOR FFL +131900
02-FIRST FLOOR FFL +128750
01-GROUND FLOOR FFL +125000

142750
136450
SIGNAGE
ENTRANCE TO UNDERCROFT

APPLICATION SITE BOUNDARY

NORTH ELEVATION
SCALE: 1 : 100

07-PARAPET LEVEL FFL +142750
06-ROOF LEVEL FFL +141350
05-FOURTH FLOOR FFL +138200
04-THIRD FLOOR FFL +135050
03-SECOND FLOOR FFL +131900
02-FIRST FLOOR FFL +128750
01-GROUND FLOOR FFL +125000
00-SUBSTATION FLOOR LEVEL FFL +124000

136450